

DLHONLINE

Fork Mounted

Jib

Model - IFJ



Description

When height is not at a premium, but maximum lift capacity is critical, the Fork Mounted Jib allows the movement of long and awkward loads from inaccessible locations with the potential of 4 different lifting centres.

Model	Capacity (kg) at Centres (mm)				Weight (kg)	C of G (mm)	LLC (mm)
	1000	1250	1500	1750			
IFJ-1.0-OP	1000	800	600	300	141	670	N/A
IFJ-1.5-OP	1500	1000	800	400	146	670	N/A
IFJ-2.0-OP	2000	1500	1000	600	152	670	N/A
IFJ-3.0-OP	3000	2000	1500	1000	159	670	N/A
IFJ-4.0-OP	4000	3000	2500	2000	171	670	N/A
IFJ-5.0-OP	5000	4000	3300	2800	183	670	N/A

Standard Features

- Multi hook positioning from 1000-1750 load centres
- Supplied complete with single swivel hook and bow shackle
- Maximum fork section 150 x 50 mm at 435 mm centres
- Zinc plated heel pins for safe attachment to truck
- Painted bright orange for safety



Dale Lifting and Handling Specialists
2 Kelbrook Road, Parkhouse Street Industrial Estate, Manchester, M11 2QA
Telephone 0161 223 1990 Email sales@dale-lifting.co.uk

INVICTA TECHNICAL FILE

OPERATION, MAINTENANCE, & HEALTH AND SAFETY INSTRUCTIONS

PRODUCT RANGE/FORK MOUNTED JIB

Operation

1. Position the forks to the correct distance apart to locate into fork pockets.
2. Remove the heel pins from the attachment.
3. Drive the forks into the fork pockets.
4. Insert fork pocket heel pins directly behind the heel of the fork and attach safety lynch pin into hole provided.
5. Position the swivel hook and shackle to the desired lifting point, ensuring that the shackle is adequately tightened.
6. The attachment is now ready for use.

Maintenance

1. The Fork Mounted Jib should be inspected weekly for general condition with particular attention paid to:
 - A – All weld points
 - B – Wear and distortion of fork pockets and heel pin attachments
 - C – Any damaged/worn components
 - D – General condition of swivel hook, safety latch and shackle
2. Damage or failure must be reported and rectified immediately prior to re-use of the attachment.
3. General surface rusting especially in the critical areas should be treated with proprietary inhibitors, primers and paint on a regular basis.
4. This product is certified for twelve (12) months from the date of manufacture after which it is the customer's responsibility to have the product re-tested at an approved testing facility or inspected and logged in a register by a competent person as advised by the HSE.

Health and Safety

1. The Manager of the department or section where the attachment is to be used must be responsible for ensuring the operators are fully conversant with the attachment, its operation, maintenance and that the heel pins are fitted correctly.
2. Ensure both the truck and attachments are capable of handling the intended load and its contents.
3. Ensure the shackle pins are adequately tightened before each use.
4. Ensure that the heel pins are correctly inserted, retained and positioned in relation to the heel of the fork prior to each and every use.
5. Do not drive into the fork pockets without removing the heel pins.
6. Ensure only vertical lifts are made and not angular lifts when using this attachment.
7. Do not shock load the attachment under any circumstances.
8. The safe working load must not be exceeded at each lifting point.

The Operator should ensure that the above product is used for the purpose that it has been designed, tested and intended to do and no deviation to this occurs. If in doubt, consult your Fork Truck Dealer or approved Attachment Supplier.